

SL2100 InMail Quick Reference Sheet

for Multiline Display Telephone

SL2100 InMail Quick Reference Sheet for Multiline Display Telephone



Using Dial Pad				
	TO SET UP YOUR INMAIL VOICE MAILBOX			
	Press the VM Soft key or			
	Dial the voice mail pilot number			
	Enter your mailbox number			
Onc	e You Are In Your Mail Box Perform the Following Steps:			
	TO RECORD PERSONAL GREETING			
	Press 4 to access the greeting menu			
	Press 1 to select your main greeting			
	Press 2 or 3 to select an alternate greeting			
	Press 7 to record a new greeting			
Sample Greeting: You have reached the voice mail of Please leave your name and call back number (s) and I will return your call as soon as possible. For immediate assistance press zero. Thank you.				
	TO RECORD YOUR NAME			
	Press 76 to access recording menu			
	Press 7 to record name			
	Press # to exit			
	TO SET SECURITY CODE			
	Press 67 to access the security code menu			
	Press 7 to enter the new security code			
	Press # to return to previous menu			
	CHECKING VOICE MAIL			
Call	Your Mailbox from Your Extension:			
	Press the VM Soft key or			
	Dial the voice mail pilot number			
	Enter your mailbox number			
	Enter your security code (if set)			

Call Your Mailbox from Outside the Company:

Note: Accessing your mailbox from outside your company requires that the mailbox has a security code. Attempts to access a mail box without a security code will receive a "**That mailbox does not exist**" prompt.

☐ Dial the company phone number that directly reaches your voice mail _

	Wait for Auto Attendant to answer.		
	Press # and your mailbox number		
	Enter security code (if set)		
Afte	r the Voice Mail Answers:		
	Press 5 to listen to your message		
	Press 77 to leave a message		
	Press 0 for complete main menu of features		
While Listening to Your Message(s)			
	Press 3to delete your message		
	Press 5 to listen to your message(s)		
	Press #to exit listen mode		
Whi	le Listening to a Message:		
	Press 73 to record a reply for the message sender		
	Press 63 to forward the message to a co-worker		
	Press 62 to make a return call to the message sender		
	Press # to exit listen mode		
	Press 84 to hear the time and date the message was sent		
	Press 72 to archive (save) the message to your mailbox		
	Press 3 to delete message		
	Press 5 to listen to the next message		
	Press 2to back up then continue listening		
	Press 22 to back up to the beginning and listen to the message		
	Press 4to go forward then continue listening		
	Press * to pause and resume listening		
	Press 16 to select a list of new messages		
	Press 17 to select list of archive messages		
	Press 12 to select list of all messages		
	Press 9 to exit mailbox		

	TO TRANSFER YOUR ACTIVE CALL TO A CO-WORKER'S MAILBOX		Forward Incoming Calls to Your Mailbox When Your Phone is Busy or You Do Answer:
	Press Transfer key.	No.	Press the Speaker key.
	Dial the co-worker's extension number.	_	Dial 744.
	Dial 8.	_	Dial 1 to set.
	(Optional) Leave message and press #.	_	Dial the VM Pilot number.
	Hang up.	_	Hang up.
	TO REDIRECT MESSAGE TO CO-WORKER'S MAILBOX		
	Press 63.		CANCEL FORWARDING TO VOICE MAIL
	(Optional) Leave message and press #.	_	Cancel Forwarding All Incoming Calls to Your Mailbox:
	Press ★ to skip recording and redirect message immediately.		Press the Speaker key.
	Dial co-worker's mailbox number.		Dial 741 .
	Press # to exit message.		Dial 0 to set.
Se	nding Calls to a Mailbox		Hang up.
		To 0	Cancel Forwarding Incoming Calls to Your Mailbox When Your Phone is Busy:
	TO FORWARD CALLS TO YOUR MAILBOX		Press the Speaker key.
To	Forward All Incoming Calls to Your Mailbox:		Dial 742 .
	Press the Speaker key.		Dial 0 to set.
	Dial 741 .		Hang up.
	Dial 1 to set.	To 0	Cancel Forwarding Incoming Calls to Your Mailbox When You Do Not Answer:
	Dial the VM Pilot number.		Press the Speaker key.
	Hang up.		Dial 743 .
To I	Forward Incoming Calls to Your Mailbox When Your Phone Is Busy:		Dial 0 to set.
	Press the Speaker key.		Hang up.
	Dial 742 .	To (Cancel Forwarding Incoming Calls to Your Mailbox When Your Phone is Busy or
	Dial 1 to set.		Do Not Answer:
	Dial the VM Pilot number.		Press the Speaker key.
	Hang up.		Dial 744 .
To I	Forward Incoming Calls to Your Mailbox When You Do Not Answer:		Dial 0 to set.
	Press the Speaker key.		Hang up.
	Dial 743 .		
	Dial 1 to set.		
	Dial the VM Pilot number.		
	Hang up.		

Voice Mail Administration Features

such as directions, hours of operation, etc.

voice Mail Administration Features	DISTRIBUTION LIST SETUP
ENTER VOICE MAIL ADMINISTRATION	From the system administrator menu:
☐ Dial the voice mail pilot number	Press 5 to enter the distribution list menu
☐ Enter your mailbox number	☐ Enter the mailbox number (001 ~ 032)
Once You Are In Your Mail Box (If You Have Administration Rights) Perform the Following Steps:	☐ Press 6 to review or modify the list ☐ Press 2 to add an extension to the distribution list
ENTER ADMINISTRATIVE MENU	☐ Press 3 to delete the current extension from the distribution list
☐ Press 72 to access the system administrator menu	☐ Press 6 to step to the next entry in the distribution list
Note: The following administrative features are only available at the system administrator's extension (extension 101 at default). Ask your NEC authorized supplier for details on how to become a system administrator.	Press # to exit this feature Press 76 to record a name for the distribution list Press 5 to listen to the name of the distribution list
TO RECORD AN INSTRUCTION MSG	Press 7 to record the name of the distribution list
☐ From the system administrator menu: ☐ Press 4 to enter the instruction message menu ☐ Enter the mailbox number (001 ~ 032) ☐ Press 5 to listen to the message ☐ Press 7 to record a new message ☐ Press 3 to delete the message ☐ Press # to return to the system administrator menu	Press 7 to record the name of the distribution list Press 3 to delete the name of the distribution list Press # to exit this feature Press # to return to the system administrator menu Note: A distribution list is a list of extensions set to receive a single voice mail message. Any message left in the distribution mailbox will be sent to all extensions in the list. SUBSCRIBER MAINTENANCE From the system administrator menu:
Note: Instruction menu messages are used as the automated attendant main greetings(e.g. day mode greeting, night mode greeting, holiday mode greeting, etc.)	☐ Press 7 to enter subscriber maintenance ☐ Enter the extension number you wish to modify
TO RECORD AN ANNOUNCEMENT MSG From the system administrator menu:	☐ Press 32 to delete all the messages in the mailbox
□ Press 2 to enter the announcement message menu □ Enter the mailbox number (001 ~ 032) □ Press 5 to listen to the message □ Press 7 to record a new message □ Press 3 to delete the message □ Press # to return to the system administrator menu	☐ Press 34
Note: Announcement menu messages are used to announce general information to callers	

	ANSWER SCHEDULE OVERRIDE
	From the system administrator menu:
	Press 6 to enter the answer schedule override menu
	Enter the mailbox number (01 ~16)
	Press 6 to toggle ON/OFF the answer schedule table
	Press 2 to enter a new answer schedule override mailbox.
	☐ Enter the override mailbox number (001 ~ 032or a valid extension)
	Press # to return to the system administrator menu
send	: Answer schedule override provides alternate answering for the automated attendant by ing calls to a specified override mailbox (when enabled). As an example you can use the vering schedule override to provide holiday and bad weather closing announcements.
	MAILBOX ANNOUNCEMENT MESSAGE
	From the system administrator menu:
	Press 3 to enter the mailbox announcement message menu
	Press 5 to listen to the mailbox announcement message
	Press 7 to record the mailbox announcement message
	Press 3 to delete the mailbox announcement message
	Press ${\bf 2}$ to specify the amount of days the mailbox announcement message is active for
	☐ Press * for an indefinite amount of days, or enter 01 ~ 99 days
	Press # to return to the system administrator menu
their	: The mailbox announcement message is played to each subscriber when they log into mailbox. This message will play each time the user logs into their mailbox until it expires, is ed, or is made inactive by the system administrator.
	VOICE MAIL VERSION
	From the system administrator menu:
	Press 8 to hear the current voice mail version

